

NEUB CSE 321 Lecture 8: 8085 Microprocessor

8085 is pronounced as "eighty-eighty-five" microprocessor. It is an 8-bit microprocessor designed by Intel in 1977 using NMOS technology.

It has the following configuration –

- 8-bit data bus
- 16-bit address bus, which can address upto 64KB
- A 16-bit program counter
- A 16-bit stack pointer
- Six 8-bit registers arranged in pairs: BC, DE, HL
- Requires +5V supply to operate at 3.2 MHz single phase clock

It is used in washing machines, microwave ovens, mobile phones, etc.

8085 Microprocessor – Functional Units

8085 consists of the following functional units –

Accumulator: It is an 8-bit register used to perform arithmetic, logical, I/O & LOAD/STORE operations. It is connected to internal data bus & ALU.

Arithmetic and logic unit: As the name suggests, it performs arithmetic and logical operations like Addition, Subtraction, AND, OR, etc. on 8-bit data.

General purpose register: There are 6 general purpose registers in 8085 processor, i.e. B, C, D, E, H & L. Each register can hold 8-bit data. These registers can work in pair to hold 16-bit data and their pairing combination is like **B-C, D-E & H-L**.

Program counter: It is a 16-bit register used to store the memory address location of the next instruction to be executed. Microprocessor increments the program whenever an instruction is being executed, so that the program counter points to the memory address of the next instruction that is going to be executed.

Stack pointer: It is also a 16-bit register works like stack, which is always incremented/decremented by 2 during push & pop operations.

Temporary register: It is an 8-bit register, which holds the temporary data of arithmetic and logical operations.

Flag register: It is an 8-bit register having five 1-bit flip-flops, which holds either 0 or 1 depending upon the result stored in the accumulator.

These are the set of 5 flip-flops –

- Sign (S)
- Zero (Z)
- Auxiliary Carry (AC)
- Parity (P)
- Carry (C)

Its bit position is shown in the following table –

D7	D6	D5	D4	D3	D2	D1	D0
S	Z		AC		P		CY

Instruction register and decoder: It is an 8-bit register. When an instruction is fetched from memory then it is stored in the Instruction register. Instruction decoder decodes the information present in the Instruction register.

Timing and control unit: It provides timing and control signal to the microprocessor to perform operations. Following are the timing and control signals, which control external and internal circuits-

- Control Signals: READY, RD', WR', ALE
- Status Signals: S0, S1, IO/M'
- DMA Signals: HOLD, HLDA
- RESET Signals: RESET IN, RESET OUT

NEUB CSE 321 Lecture 8: 8085 Microprocessor

Interrupt control: As the name suggests it controls the interrupts during a process. When a microprocessor is executing a main program and whenever an interrupt occurs, the microprocessor shifts the control from the main program to process the incoming request. After the request is completed, the control goes back to the main program.


There are 5 interrupt signals in 8085 microprocessor: INTR, RST 7.5, RST 6.5, RST 5.5, TRAP.

Serial Input/output control: It controls the serial data communication by using these two instructions: SID (Serial input data) and SOD (Serial output data).

Address buffer and address-data buffer: The content stored in the stack pointer and program counter is loaded into the address buffer and address-data buffer to communicate with the CPU. The memory and I/O chips are connected to these buses; the CPU can exchange the desired data with the memory and I/O chips.


Address bus and data bus: Data bus carries the data to be stored. It is bidirectional, whereas address bus carries the location to where it should be stored and it is unidirectional. It is used to transfer the data & Address I/O devices.

8085 Architecture



The following image depicts the pin diagram of 8085 Microprocessor –

NEUB CSE 321 Lecture 8: 8085 Microprocessor



The pins of a 8085 microprocessor can be classified into seven groups –

Address bus: A15-A8, it carries the most significant 8-bits of memory/IO address.

Data bus: AD7-AD0, it carries the least significant 8-bit address and data bus.

Control and status signals: These signals are used to identify the nature of operation. There are 3 control signal and 3 status signals.

Three control signals are RD, WR & ALE.

- **RD** – This signal indicates that the selected IO or memory device is to be read and is ready for accepting data available on the data bus.
- **WR** – This signal indicates that the data on the data bus is to be written into a selected memory or IO location.
- **ALE** – It is a positive going pulse generated when a new operation is started by the microprocessor. When the pulse goes high, it indicates address. When the pulse goes down it indicates data.

Three status signals are IO/M, S₀ & S₁.

IO/M: This signal is used to differentiate between IO and Memory operations, i.e. when it is high indicates IO operation and when it is low then it indicates memory operation.

S₁ & S₀: These signals are used to identify the type of current operation.

Power supply: There are 2 power supply signals – VCC & VSS. VCC indicates +5v power supply and VSS indicates ground signal.

Clock signals: There are 3 clock signals, i.e. X1, X2, CLK OUT.

- **X1, X2** – A crystal (RC, LC N/W) is connected at these two pins and is used to set frequency of the internal clock generator. This frequency is internally divided by 2.
- **CLK OUT** – This signal is used as the system clock for devices connected with the microprocessor.

Interrupts & externally initiated signals

Interrupts are the signals generated by external devices to request the microprocessor to perform a task. There are 5 interrupt signals, i.e. TRAP, RST 7.5, RST 6.5, RST 5.5, and INTR. We will discuss interrupts in detail in interrupts section.

- **INTA** – It is an interrupt acknowledgment signal.
- **RESET IN** – This signal is used to reset the microprocessor by setting the program counter to zero.
- **RESET OUT** – This signal is used to reset all the connected devices when the microprocessor is reset.

NEUB CSE 321 Lecture 8: 8085 Microprocessor

- **READY** – This signal indicates that the device is ready to send or receive data. If READY is low, then the CPU has to wait for READY to go high.
- **HOLD** – This signal indicates that another master is requesting the use of the address and data buses.
- **HLDA (HOLD Acknowledge)** – It indicates that the CPU has received the HOLD request and it will relinquish the bus in the next clock cycle. HLDA is set to low after the HOLD signal is removed.

Serial I/O signals

There are 2 serial signals, i.e. SID and SOD and these signals are used for serial communication.

- **SOD** (Serial output data line) – The output SOD is set/reset as specified by the SIM instruction.
- **SID** (Serial input data line) – The data on this line is loaded into accumulator whenever a RIM instruction is executed.

Addressing Modes in 8085

These are the instructions used to transfer the data from one register to another register, from the memory to the register, and from the register to the memory without any alteration in the content.

8085 has 5 addressing modes

1. **Direct Addressing Mode:** In this type of addressing mode, the 16bit memory address is directly provided with the instruction.
Example: `LDA C5 00` etc
2. **Indirect Addressing Mode:** In this type of addressing mode, the 16bit memory address is indirectly provided with the instruction using a register pair
Example: `LDAX B` (Load the accumulator with the contents of the memory location whose address is stored in the register pair BC)
3. **Register Addressing mode:** This type of addressing mode specifies register or register pair that contains data.
Example: `ADD B, MOV B A`
4. **Implied Addressing mode:** In this type of addressing mode, No operand (register or data) is specified in the instruction. The operand is inherent to the instruction.
Example: `CMA` (Complement Accumulator) , `SIM` , `RIM` etc
5. **Immediate Addressing Mode:** In this type of addressing mode, immediate data byte is provided with the instruction.
Example: `MVI A 47H, MVIB CFH` etc.

Interrupts in 8085

Interrupts are the signals generated by the external devices to request the microprocessor to perform a task. There are 5 interrupt signals, i.e. TRAP, RST 7.5, RST 6.5, RST 5.5, and INTR.

Interrupt are classified into following groups based on their parameter –

- **Vector interrupt** – In this type of interrupt, the interrupt address is known to the processor.
For example: RST7.5, RST6.5, RST5.5, TRAP.
- **Non-Vector interrupt** – In this type of interrupt, the interrupt address is not known to the processor so, the interrupt address needs to be sent externally by the device to perform interrupts. **For example:** INTR.
- **Maskable interrupt** – In this type of interrupt, we can disable the interrupt by writing some instructions into the program. **For example:** RST7.5, RST6.5, RST5.5.

NEUB CSE 321 Lecture 8: 8085 Microprocessor

- **Non-Maskable interrupt** – In this type of interrupt, we cannot disable the interrupt by writing some instructions into the program. **For example:** TRAP.
- **Software interrupt** – In this type of interrupt, the programmer has to add the instructions into the program to execute the interrupt. There are 8 software interrupts in 8085, i.e. RST0, RST1, RST2, RST3, RST4, RST5, RST6, and RST7.
- **Hardware interrupt** – There are 5 interrupt pins in 8085 used as hardware interrupts, i.e. TRAP, RST7.5, RST6.5, RST5.5, INTA.

Note – NTA is not an interrupt, it is used by the microprocessor for sending acknowledgement. TRAP has the highest priority, then RST7.5 and so on.

Interrupt Service Routine (ISR): A small program or a routine that when executed, services the corresponding interrupting source is called an ISR.

TRAP: It is a non-maskable interrupt, having the highest priority among all interrupts. By default, it is enabled until it gets acknowledged. In case of failure, it executes as ISR and sends the data to backup memory. This interrupt transfers the control to the location 0024H.

RST7.5: It is a maskable interrupt, having the second highest priority among all interrupts. When this interrupt is executed, the processor saves the content of the PC register into the stack and branches to 003CH address.

RST 6.5: It is a maskable interrupt, having the third highest priority among all interrupts. When this interrupt is executed, the processor saves the content of the PC register into the stack and branches to 0034H address.

RST 5.5: It is a maskable interrupt. When this interrupt is executed, the processor saves the content of the PC register into the stack and branches to 002CH address.

INTR: It is a maskable interrupt, having the lowest priority among all interrupts. It can be disabled by resetting the microprocessor.

When **INTR signal goes high**, the following events can occur –

- The microprocessor checks the status of INTR signal during the execution of each instruction.
- When the INTR signal is high, then the microprocessor completes its current instruction and sends active low interrupt acknowledge signal.
- When instructions are received, then the microprocessor saves the address of the next instruction on stack and executes the received instruction.

Summary of 8085 registers

Intel 8085 registers		
1 ₅ 1 ₄ 1 ₃ 1 ₂ 1 ₁ 1 ₀ 0 ₉ 0 ₈ 0 ₇ 0 ₆ 0 ₅ 0 ₄ 0 ₃ 0 ₂ 0 ₁ 0 ₀ (bit position)		
Main registers		
A	Flags	Program Status Word
B	C	B
D	E	D
H	L	H (indirect address)
Index registers		
SP		Stack Pointer
Program counter		
PC		Program Counter
Status register		
S Z - AC - P - CY		Flags

NEUB CSE 321 Lecture 8: 8085 Microprocessor

Instruction set of 8085

Instruction sets are instruction codes to perform some task. Instruction set of 8085 is classified into five categories.

Control instructions

Opcode	Operand	Meaning	Explanation
NOP	None	No operation	No operation is performed, i.e., the instruction is fetched and decoded.
HLT	None	Halt and enter wait state	The CPU finishes executing the current instruction and stops further execution. An interrupt or reset is necessary to exit from the halt state.
DI	None	Disable interrupts	The interrupt enable flip-flop is reset and all the interrupts are disabled except TRAP.
EI	None	Enable interrupts	The interrupt enable flip-flop is set and all the interrupts are enabled.
RIM	None	Read interrupt mask	This instruction is used to read the status of interrupts 7.5, 6.5, 5.5 and read serial data input bit.
SIM	None	Set interrupt mask	This instruction is used to implement the interrupts 7.5, 6.5, 5.5, and serial data output.

Logical instructions

Opcode	Operand	Meaning	Explanation
CMP	R M	Compare the register or memory with the accumulator	The contents of the operand (register or memory) are M compared with the contents of the accumulator.
CPI	8-bit data	Compare immediate with the accumulator	The second byte data is compared with the contents of the accumulator.
ANA	R M	Logical AND register or memory with the accumulator	The contents of the accumulator are logically AND with M the contents of the register or memory, and the result is placed in the accumulator.
ANI	8-bit data	Logical AND immediate with the accumulator	The contents of the accumulator are logically AND with the 8-bit data and the result is placed in the accumulator.
XRA	R M	Exclusive OR register or memory with the accumulator	The contents of the accumulator are Exclusive OR with M the contents of the register or memory, and the result is placed in the accumulator.
XRI	8-bit data	Exclusive OR immediate with the accumulator	The contents of the accumulator are Exclusive OR with the 8-bit data and the result is placed in the accumulator.
ORA	R M	Logical OR register or memory with the accumulator	The contents of the accumulator are logically OR with M the contents of the register or memory, and result is placed in the accumulator.
ORI	8-bit data	Logical OR	The contents of the accumulator are logically OR

NEUB CSE 321 Lecture 8: 8085 Microprocessor

		immediate with the accumulator	with the 8-bit data and the result is placed in the accumulator.
RLC	None	Rotate the accumulator left	Each binary bit of the accumulator is rotated left by one position. Bit D7 is placed in the position of D0 as well as in the Carry flag. CY is modified according to bit D7.
RRC	None	Rotate the accumulator right	Each binary bit of the accumulator is rotated right by one position. Bit D0 is placed in the position of D7 as well as in the Carry flag. CY is modified according to bit D0.
RAL	None	Rotate the accumulator left through carry	Each binary bit of the accumulator is rotated left by one position through the Carry flag. Bit D7 is placed in the Carry flag, and the Carry flag is placed in the least significant position D0. CY is modified according to bit D7.
RAR	None	Rotate the accumulator right through carry	Each binary bit of the accumulator is rotated right by one position through the Carry flag. Bit D0 is placed in the Carry flag, and the Carry flag is placed in the most significant position D7. CY is modified according to bit D0.
CMA	None	Complement accumulator	The contents of the accumulator are complemented. No flags are affected.
CMC	None	Complement carry	The Carry flag is complemented. No other flags are affected.
STC	None	Set Carry	Set Carry

Branching Instructions

Opcode	Operand	Meaning	Explanation
JMP	16-bit address	Jump unconditionally	The program sequence is transferred to the memory address given in the operand.
Opcode Description Flag Status JC Jump on Carry CY=1 JNC Jump on no Carry CY=0 JP Jump on positive S=0 JM Jump on minus S=1 JZ Jump on zero Z=1 JNZ Jump on no zero Z=0 JPE Jump on parity even P=1 JPO Jump on parity P=0	16-bit address	Jump conditionally	The program sequence is transferred to the memory address given in the operand based on the specified flag of the PSW.

NEUB CSE 321 Lecture 8: 8085 Microprocessor

odd				
Opcode Description	Flag Status	16-bit address	Unconditional subroutine call	The program sequence is transferred to the memory address given in the operand. Before transferring, the address of the next instruction after CALL is pushed onto the stack.
CC	Call on Carry CY=1			
CNC	Call on no Carry CY=0			
CP	Call on positive S=0			
CM	Call on minus S=1			
CZ	Call on zero Z=1			
CNZ	Call on no zero Z=0			
CPE	Call on parity even P=1			
CPO	Call on parity odd P=0			
RET		None	Return from subroutine unconditionally	The program sequence is transferred from the subroutine to the calling program.
Opcode Description	Flag Status	None	Return from subroutine conditionally	The program sequence is transferred from the subroutine to the calling program based on the specified flag of the PSW and the program execution begins at the new address.
RC	Return on Carry CY=1			
RNC	Return on no Carry CY=0			
RP	Return on positive S=0			
RM	Return on minus S=1			
RZ	Return on zero Z=1			
RNZ	Return on no zero Z=0			
RPE	Return on parity even P=1			
RPO	Return on parity odd P=0			
PCHL		None	Load the program counter with HL contents	The contents of registers H & L are copied into the program counter. The contents of H are placed as the high-order byte and the contents of L as the loworder byte.
RST		0-7	Restart	The RST instruction is used as software instructions in a program to transfer the program execution to one of the following

NEUB CSE 321 Lecture 8: 8085 Microprocessor

		<p>eight locations.</p> <p>Instruction Restart Address</p> <p>RST 0 0000H</p> <p>RST 1 0008H</p> <p>RST 2 0010H</p> <p>RST 3 0018H</p> <p>RST 4 0020H</p> <p>RST 5 0028H</p> <p>RST 6 0030H</p> <p>RST 7 0038H</p> <p>The 8085 has additionally 4 interrupts, which can generate RST instructions internally and doesn't require any external hardware. Following are those instructions and their Restart addresses –</p> <p>Interrupt Restart Address</p> <p>TRAP 0024H</p> <p>RST 5.5 002CH</p> <p>RST 6.5 0034H</p> <p>RST 7.5 003CH</p>
--	--	--

Arithmetic instructions

Opcode	Operand	Meaning	Explanation
ADD	R M	Add register or memory, to the accumulator	The contents of the register or memory are added to the contents of the accumulator and the result is stored in the accumulator. Example – ADD K.
ADC	R M	Add register to the accumulator with carry	The contents of the register or memory & M the Carry flag are added to the contents of the accumulator and the result is stored in the accumulator. Example – ADC K
ADI	8-bit data	Add the immediate to the accumulator	The 8-bit data is added to the contents of the accumulator and the result is stored in the accumulator. Example – ADI 55K
ACI	8-bit data	Add the immediate to the accumulator with carry	The 8-bit data and the Carry flag are added to the contents of the accumulator and the result is stored in the accumulator. Example – ACI 55K

NEUB CSE 321 Lecture 8: 8085 Microprocessor

LXI	Reg. pair, 16bit data	Load the register pair immediate	The instruction stores 16-bit data into the register pair designated in the operand. Example – LXI K, 3025M
DAD	Reg. pair	Add the register pair to H and L registers	The 16-bit data of the specified register pair are added to the contents of the HL register. Example – DAD K
SUB	R M	Subtract the register or the memory from the accumulator	The contents of the register or the memory are subtracted from the contents of the accumulator, and the result is stored in the accumulator. Example – SUB K
SBB	R M	Subtract the source and borrow from the accumulator	The contents of the register or the memory & M the Borrow flag are subtracted from the contents of the accumulator and the result is placed in the accumulator. Example – SBB K
SUI	8-bit data	Subtract the immediate from the accumulator	The 8-bit data is subtracted from the contents of the accumulator & the result is stored in the accumulator. Example – SUI 55K
SBI	8-bit data	Subtract the immediate from the accumulator with borrow	The contents of register H are exchanged with the contents of register D, and the contents of register L are exchanged with the contents of register E. Example – XCHG
INR	R M	Increment the register or the memory by 1	The contents of the designated register or the memory are incremented by 1 and their result is stored at the same place. Example – INR K
INX	R	Increment register pair by 1	The contents of the designated register pair are incremented by 1 and their result is stored at the same place. Example – INX K
DCR	R M	Decrement the register or the memory by 1	The contents of the designated register or memory are decremented by 1 and their result is stored at the same place. Example – DCR K
DCX	R	Decrement the register pair by 1	The contents of the designated register pair are decremented by 1 and their result is stored at the same place. Example – DCX K
DAA	None	Decimal adjust accumulator	The contents of the accumulator are changed from a binary value to two 4-bit BCD digits. If the value of the low-order 4-bits in the accumulator is greater than 9 or if AC flag is set, the instruction adds 6 to the low-order four bits.

NEUB CSE 321 Lecture 8: 8085 Microprocessor

			<p>If the value of the high-order 4-bits in the accumulator is greater than 9 or if the Carry flag is set, the instruction adds 6 to the high-order four bits.</p> <p>Example – DAA</p>
--	--	--	--

Data transfer instructions

Opcode	Operand	Meaning	Explanation
MOV	Rd, Sc M, Sc Dt, M	Copy from the source (Sc) to the destination(Dt)	This instruction copies the contents of the source register into the destination register without any alteration. Example – MOV K, L
MVI	Rd, data M, data	Move immediate 8-bit	The 8-bit data is stored in the destination register or memory. Example – MVI K, 55L
LDA	16-bit address	Load the accumulator	The contents of a memory location, specified by a 16-bit address in the operand, are copied to the accumulator. Example – LDA 2034K
LDAX	B/D Reg. pair	Load the accumulator indirect	The contents of the designated register pair point to a memory location. This instruction copies the contents of that memory location into the accumulator. Example – LDAX K
LXI	Reg. pair, 16-bit data	Load the register pair immediate	The instruction loads 16-bit data in the register pair designated in the register or the memory. Example – LXI K, 3225L
LHLD	16-bit address	Load H and L registers direct	The instruction copies the contents of the memory location pointed out by the address into register L and copies the contents of the next memory location into register H. Example – LHLD 3225K
STA	16-bit address	16-bit address	The contents of the accumulator are copied into the memory location specified by the operand. This is a 3-byte instruction, the second byte specifies the low-order address and the third byte specifies the high-order address. Example – STA 325K
STAX	16-bit address	Store the accumulator indirect	The contents of the accumulator are copied into the memory location specified by the contents of the operand. Example – STAX K
SHLD	16-bit address	Store H and L registers direct	The contents of register L are stored in the memory location specified by the 16-bit address in the operand and the contents of H register are stored into the next memory location by incrementing the operand. This is a 3-byte instruction, the second byte specifies the low-order address and the third byte specifies the high-order address. Example – SHLD 3225K

NEUB CSE 321 Lecture 8: 8085 Microprocessor

XCHG	None	Exchange H and L with D and E	The contents of register H are exchanged with the contents of register D, and the contents of register L are exchanged with the contents of register E. Example – XCHG
SPHL	None	Copy H and L registers to the stack pointer	The instruction loads the contents of the H and L registers into the stack pointer register. The contents of the H register provide the high-order address and the contents of the L register provide the low-order address. Example – SPHL
XTHL	None	Exchange H and L with top of stack	The contents of the L register are exchanged with the stack location pointed out by the contents of the stack pointer register. The contents of the H register are exchanged with the next stack location (SP+1). Example – XTHL
PUSH	Reg. pair	Push the register pair onto the stack	The contents of the register pair designated in the operand are copied onto the stack in the following sequence. The stack pointer register is decremented and the contents of the high order register (B, D, H, A) are copied into that location. The stack pointer register is decremented again and the contents of the low-order register (C, E, L, flags) are copied to that location. Example – PUSH K
POP	Reg. pair	Pop off stack to the register pair	The contents of the memory location pointed out by the stack pointer register are copied to the low-order register (C, E, L, status flags) of the operand. The stack pointer is incremented by 1 and the contents of that memory location are copied to the high-order register (B, D, H, A) of the operand. The stack pointer register is again incremented by 1. Example – POPK
OUT	8-bit port address	Output the data from the accumulator to a port with 8bit address	The contents of the accumulator are copied into the I/O port specified by the operand. Example – OUT K9L
IN	8-bit port address	Input data to accumulator from a port with 8-bit address	The contents of the input port designated in the operand are read and loaded into the accumulator. Example – IN5KL